





8081F and 8091F

Weatherproof FS Outlet Box

For installing devices on all siding types. Paintable, UV rated plastic for long outdoor life.

	UPC/DCI/NAED MFG #018997	SIDING TYPE			DIM A		DIM C
FS8091F	17304	All Types	10	10	4.511	6.558	3.100



MADE IN USA. SE

Add suffix "GC" to Catalog # when ordering in Canada to include grounding clip, for example FS8091FGC.

FEATURES AND BENEFITS

 Installs before or after siding is installed. Remove break away flanges for installation on previously sided structures.

· For use with all single-gang devices, including GFCIs

- · Can be installed vertically or horizontally • Textured paintable surface.
- For all types of siding



· Costs less with a one piece design

INSTALLATION INSTRUCTIONS

BEFORE Siding is Up

- 1) Disconnect electrical power. Remove knockout. Insert cable connector. Pull NM cable through connector.
- 2) Attach outlet box to substrate with (2) screws.
- 3) Install device, FS8091F works with all single gang devices. Complete installation with code required weatherproof while in use cover



AFTER Siding is Up

- 1) Disconnect electrical power. Cut hole in siding.
- 2) Break flanges off the back of the FS8091F. Remove knockout. Insert cable connector in KO,
- 3) Attach outlet box to substrate with (2) screws.
- 4) Install single gang device (standard or GFCI). Complete installation with code required weatherproof while in use cover



