



Scan For Video



## TV Bridge™ II Kits

Non-metallic pre-wired, pre-assembled box kits for flat screen TV installations.

| CATALOG NUMBER | UPC/DCI/NAED MFG #018997 | DESCRIPTION  | UNIT PKG | STD PKG |
|----------------|--------------------------|--|----------|---------|
| TVBRA1K        | 24180                    | w/ Single-gang boxes   | 1        | 1       |
| TVBRA2K        | 24181                    | w/ 2-Gang power/low voltage box  | 1        | 1       |
| TVBRA3K        | 24195                    | 2-Gang power/low voltage upper box, single gang (lower)                | 1        | 1       |
| TVB712BK       | 12781                    | Single-gang angled power upper box, 2-gang power/low voltage lower box | 1        | 1       |



Add suffix "GC" to Catalog # when ordering in Canada to include grounding clip, for example TVBRA1KGC.

### CATALOG NUMBER

### KIT CONTENTS

- TVBRA1K** Single-gang recessed box containing an outlet connected to 7 ft. of NM cable. Second single-gang recessed box connected to the NM cable. Includes pre-wired 4 ft. 110V outlet plug, trim, and face plate.
- TVBRA2K** 2-Gang recessed box containing low voltage & power outlet connected to 7 ft. of NM cable. Second 2-gang recessed box containing low voltage & power connected to the NM cable. Includes pre-wired 4 ft. 110V outlet plug, trim plate, and face plate.
- TVBRA3K** 2-Gang recessed box containing low voltage & power outlet connected to 7 ft. of NM cable. Second single gang recessed box connected to the NM cable. Includes pre-wired 4 ft. 110V outlet plug, trim, and face plate.
- TVB712BK** Single-gang recessed box containing an angled power outlet connected to 7 ft. of NM cable. Second 2-gang recessed box containing low voltage & power connected to the NM cable. Includes a pre-wired 4 ft. 110V outlet plug, trim plate, and face plate.

### INSTALLATION INSTRUCTIONS



1) Cut Top hole in wall for the TV. Cut Lower hole directly below the top hole, close to existing outlet. Drop the pre-wired device box assembly and cable through the top hole. Insert box and tighten wings.



2) Pull pre-wired device assembly through the bottom hole.



3) Attach device box to trim plate with screws provided. Secure trim plate to wall with mounting wing screws. Install CED130 in 2-Gang boxes. Pull cables.

