


Floorbox Coverplate Kit Single-Gang, Flip-Door Style

Manufacturers of Quality Electrical Products



AI CAT. #
FLB5331MB (BRASS)
FLB5331NL (NICKEL)

<u>WARNING</u>: Make sure power is OFF at main panel box before installing.

## INSTALLATION INSTRUCTIONS

- 1. Cut electical box into subfloor/finished floor, avoiding floor joists. For finish floor thickness greater than 1/2" thick, box will need to be routed so the outside mounting tabs are 1/4"-1/2" recessed into finished floor. Adjust outside mounting tabs on electrical box so that receptacle mounting tabs are recessed approximately 1/4"
- 2. Ensure that receptacle mounting location is clear of any subfloor/flooring material so #6-32 screws can extend past floor surface
- 3. Install appropriate fitting & pull cable
- 4. Secure electrical box with four screws through outside tabs. (screws not provided)
- 5. When attaching box to sub-floor, finish floor surface should be brought up to long sides of electrical box and within a 1/2" of mounting ears on short sides of box. IMPORTANT: Finished floor surface must cover outside tabs by a minimum of 1/4"
- 6. Wire receptacle in accordance with National (NEC/CEC), state/province, and local codes
- 7. Attach gasket support plate to receptacle with  $\#6-32 \times 1/2$ " long screw.
- 8. Place gasket on top of gasket support plate.
- 9. Install coverplate using #6-32  $\times$  1-3/16 long screws.

If you have any questions or if parts are missing Please call our Customer Service Department at 1-800-233-4717. Do not call or return this product to your local store or distributor.

