

Installation Instructions:

- 1. Determine location to install FLBA101 / FLBAR101 Adjustable Floor Box avoiding floor joist.
- 2. Cut a 2-3/8" x 3-3/4" hole in floor.
- 3. Install NM94 Connector in opening to be used in Box & install NM900 Plug in the other opening.
- 4. Pull cable through the NM94 Connector.
- 5. Install Box to floor by attaching top of bracket with (2) #6 Drywall Screws (provided) to floor.
- 6. Adjust top of Box to finished floor height.
- 7. Wire receptacle and install in box.
- 8. Install Back Plate using (1) #6-32 screw provided.
- 9. Install Metal Clip with (2) #6 Drywall screws provided.
- 10. Install Cover Plate using (4) #6-32 screws provided and insert Cap in adjusting hole.

The manufacturer and distributor warrant this product for material and workmanship only, and shall not be liable for any special incident or consequential damages or for damages or loss caused by improper use or installation.

Questions/Parts Missing: Please call our Customer Service Department at 1-800-233-4717. Do not call or return this product to your local store or distributor.

Wire Receptacle per NEC, State, and Local Codes.