

If you have any questions or if parts are missing from your FLBC8500 Gangable Floor Box Kit, please call our Customer Service Department at 1-800-233-4717. Do not call or return this product to your local store or distributor.

## Installation Instructions

- Cut knockouts to use 1" conduit hubs and/or connecting multiple (up to 3) FLOOR BOXES.
  <u>Note</u>: Provided 1-1/4" PLUGS have knockouts to use 1" conduit in 1-1/4" hubs. Cut knockouts from 1-1/4" PLUGS to use 1" conduit. 1-1/4" to 3/4" REDUCING BOXES can be used for 3/4" conduit.
- If 2 or 3 boxes are to be ganged together, interlock FLOOR BOXES as shown above.
- Set FLOOR BOX(es) into position and secure in place thru molded mounting holes.
- Install conduit as needed securing with PVC cement (not supplied).
- Pull wires thru conduit as required.
- Install 1-1/4" PLUGS with PVC cement to seal unused openings.
- Install MUD COVER into FLOOR BOX(es).
- Pour concrete to desired depth.

## - After concrete has cured, use saw to cut FLOOR BOX(es) to FINISHED FLOOR HEIGHT.

WARNING: Make sure power is OFF at main panel box before installing.

NOTE: All wiring must be according to NEC, State and Local codes.

The manufacturer warrants this product for material and workmanship only, and shall not be liable for any special, incidental, or consequential damages or for damages or loss caused by improper use or installation.