

CUT IN BOX KITS

NON-METALLIC BOX • 4" METAL COVERS





METAL COVERS WITH FLIP LIDS...

CATALOG	UPC/DCI/NAED	CUT IN™	UNIT/STD
NUMBER	MFG. #018997	FLOOR BOX KITS	PKG

Single FLIP LID • Non-metallic box

FLB3531MB	00745	Brass cover	1
FLB3531NL	00746	NIckel-plated Brass cover	1

Two FLIP LIDS • Non-metallic box

-	<u> </u>		9	
10			ε.	
00	١.	2	8	
-91	11	\cup	μ.	

FLB3532NL

FLB3532MB	48017	Brass cover	1	
ELBI3 573 28ND X KITS	48019	NIckel-plated Brass cover	1	
include non-metallic box, round 4" diameter metal cover with flip lid(s),				
non-metallic gasket support plate, gasket, gasket, UL Listed 15 amp				
TR duplex receptacle, NM94 and NM95 cable connectors, (3) #8 x 1/2"				
flat head screws and (1) #6 x 1/2" screw.				



NUMBER	MFG. #018997	TRIM KITS	PKG	STR.
Single FLIP D	DOOR			FLB3531MBTK
FLB3531MB	TK 00747	Brass cover	1	
EI DZEZ INI T	W 00749	Nickol platod Prace	1	

UNIT/STD

FLB3531NL1K	00748	Nickel-plated Brass	1

UPC/DCI/NAED METAL COVER

Two FLIP LIDS

CATALOG

 FLB35322MBTK
 48018
 Brass cover
 1

 COVER TRIM KITS include round 4" diameter metal cover with flip lid(s), gaskets, UL Listed 15 amp TR duplex receptacle
 1

CATALOG	UPC/DCI/NAED	METAL	UNIT/STD	
NUMBER	MFG. #018997	CARPET RING	PKG	
for FLB3531TK and FLB3532TK KITS				

IOI FLDJJJIIN AIIU FLDJJJJIN NIIJ				
FLB3530MB	16900	Brass	1	
FBB3530NCOVERS CUI @90% of Carpatckel-plated Brass			1	







with Two Hole Saw Cuts

1 Using a 4" diameter hole saw, cut opening in floor approximately 1/2" deep. Avoid structural framing members.



2 Next, use a 3-1/2" hole saw to cut through the remaining flooring/subfloor, creating a shelf at the desired box depth..



3 Remove material that remains between saw cuts.



4 Pull cable. Install in box with supplied cable connector. Attach box to floor with (3) #6 x 1-1/4" wood screws (not supplied) through U-shaped cut outs in box flange.



5 Wire receptacle. Install in box.

rlington 800

800.233.4717 • www.aifittings.com • EMAIL sales@aifittings.com